

**Ohm-table for:**  
**Framledningsgivare/supply pipe sensor:**  
 Thermomatic EC Home, CBJ, K, ERA 10,  
 ERA 10PE+, ERA K & Combi

**+ standardgivare/sensors:**  
 Laddomat MR, 3000  
 Laddomat 630.2, 650.2, 655.2

**Sensor type: NTC 50 kOhm @ 25°C**

Temperature	Resistance (kOhm)		
0°	161 kΩ		
+5°	126 kΩ		
+10°	99 kΩ		
+15°	78 kΩ		
+20°	62 kΩ		
+25°	50 kΩ		
+30°	40 kΩ		
+35°	33 kΩ		
+40°	27 kΩ		
+45°	22 kΩ		
+50°	18 kΩ		
+55°	15 kΩ		
+60°	12 kΩ		
+65°	10 kΩ		
+70°	9 kΩ		
+75°	7 kΩ		
+80°	6 kΩ		
+85°	5 kΩ		
+90°	4 kΩ		